

BILCO Type LadderUP® Safety Posts provide easier, safer ladder access through roof hatches, floor access doors, and manholes. This telescoping post permanently mounts to the top two rungs of any fixed ladder, providing a positive hand-hold and enabling the user to enter or exit an opening in an upright and balanced position. For more information, please visit our website [www.bilco.com](http://www.bilco.com) or call 1-800-366-6530.

## SECTION 077233

### ROOF HATCHES

#### (BILCO TYPE LU)

#### PART 1 - GENERAL

##### 1.1 SUMMARY

- A. Work Included: Provide factory-fabricated ladder safety posts.

##### 1.2 SUBMITTALS

- A. Product Data: Submit manufacturer's product data.
- B. Shop Drawings: Submit shop drawings including profiles, accessories, location, adjacent construction interface, and dimensions.
- C. Warranty: Submit executed copy of manufacturer's standard warranty.

##### 1.3 QUALITY ASSURANCE

- A. Manufacturer: A minimum of 5 years experience manufacturing similar products.
- B. Installer: A minimum of 2 years experience installing similar products.
- C. Manufacturer's Quality System: Registered to ISO 9001 Quality Standards including in-house engineering for product design activities.

##### 1.4 DELIVERY, STORAGE AND HANDLING

- A. Deliver products in manufacturer's original packaging. Store materials in a dry, protected, well-ventilated area. Inspect product upon receipt and report damaged material immediately to delivering carrier and note such damage on the carrier's freight bill of lading.

##### 1.5 WARRANTY

- A. Manufacturer's Warranty: Provide manufacturer's standard warranty. Materials shall be free of defects in material and workmanship for a period of five years from the date of purchase. Should a part fail to function in normal use within this period, manufacturer shall furnish a new part at no charge.

## PART 2 - PRODUCTS

### 2.1 MANUFACTURER

- A. Basis-of-Design Manufacturer: Type LU Ladder Safety Post by The BILCO Company, P.O. Box 1203, New Haven, CT 06505, 1-800-366-6530, Fax: 1-203-535-1582, Web: www.bilco.com. Comply with the following:

### 2.2 LADDER SAFETY POST

- A. Furnish and install where indicated on plans ladder safety post Model [insert LU-1, LU-2, LU-3, or LU-4]. The ladder safety post shall be pre-assembled from the manufacturer.
- B. Performance characteristics:
  - 1. Tubular post shall lock automatically when fully extended.
  - 2. Safety post shall have controlled upward and downward movement.
  - 3. Release lever shall disengage the post to allow it to be returned to its lowered position.
  - 4. Post shall have adjustable mounting brackets to fit ladder rung spacing up to 14" (356mm) on center and clamp brackets to accommodate ladder rungs up to 1-3/4" (44mm) in diameter.
- C. Post: Shall be manufactured of high strength square tubing. A pull up loop shall be provided at the upper end of the post to facilitate raising the post.
- D. Material of construction: Shall be [insert: steel (Model LU-1, LU-2); or Type 304 stainless steel (Model LU-3); or aluminum (Model LU-4)].
- E. Balancing spring: A stainless steel spring balancing mechanism shall be provided to provide smooth, easy, controlled operation when raising and lowering the safety post. [For installation in highly corrosive atmospheres, Model LU-3 incorporates a special alloy spring mechanism].
- F. Hardware: All mounting hardware shall be Type 316 stainless steel.
- G. Finishes: Factory finish shall be [insert: yellow powder coat steel (Model LU-1); or hot dip galvanized steel (Model LU-2); or mill finish stainless steel (Model LU-3); or mill finish aluminum (LU-4)].

## PART 3 - EXECUTION

### 3.1 EXAMINATION

- A. Examine substrates and openings for compliance with requirements for installation tolerances and other conditions affecting performance. Proceed with installation only after unsatisfactory conditions have been corrected.

### 3.2 INSTALLATION

- A. Install products in strict accordance with manufacturer's instructions and approved submittals. Locate units level, plumb, and in proper alignment with adjacent work.
  - 1. Test units for proper function and adjust until proper operation is achieved.
  - 2. Repair finishes damaged during installation.
  - 3. Restore finishes so no evidence remains of corrective work.

3.3 ADJUSTING AND CLEANING

- A. Clean exposed surfaces using methods acceptable to the manufacturer which will not damage finish.

END OF SECTION